


DOGPOWEREDSCOOTER "OUTRIGGER"
 WWW.DOGPOWEREDSCOOTER.COM (SEARCH "GOOGLE.COM" UNDER "DOGPOWEREDSCOOTER")
 MARK SCHUETTE
 434 S.E. CLEVELAND AVE.
 BEND, OREGON 97102
 541-383-3845

REMOVE STOCK FOOTPLATE AND REPLACE W/ ALUM. OUTRIGGER PLATE BOLT DOWN TO FRAME BRACES BELOW (NOT SO TIGHT AS TO BEND THE BRACES) THEN BOLT OUTRIGGER BAR DOWN TO PLATE IN THE 3 PLACES - BEFORE FINAL TIGHTENING SIGHT DOWN BAR AND MAKE SURE IT RUNS PARALLEL TO SCOOTER.



USE FLEXIBLE BRAKE CABLE ELBOW AT THE REAR

FOOTPLATE FLUSH THIS SIDE



THIS HELPS THE OUTSIDE HARNESS CONNECTION ENGAGE AT THE SAME TIME AS THE INNER SO THAT THE PULL ON THE HARNESS IS EQUALIZED.
 REMOVE KICKSTAND - NOT NEEDED

RUBBER STRAP & SPRING SHOCK ABSORBER AT REAR OF OUTRIGGER
 KEEP SOME GREASE ON BOLT WHERE STRAPS SLIDE



BRIEFLY - PUTTING THE SCOOTER TOGETHER:
 GET ALL THE PARTS OUT OF THE BOX - LOOK FOR THE REAR FENDER CABLE SHEATHING WHICH MAY BE LOOSE TAKE OFF STOCK FOOTPLATE AND KICKSTAND CLAMP BOTTOM OF SCOOTER FRAME ACROSS CORNER OF TABLE PUT ON WHEELS PUT ON HANDLEBARS DO INITIAL BRAKE CABLES ORIENTATION INSTALL BRAKE CABLES - DON'T FORGET RUBBER BOOTS AT CALIPERS BEGIN AT HANDLEBARS BY INSERTING CABLE END DRUM INTO LEVERS FINCH BRAKE CALIPERS TOGETHER LOOSELY THEN TIGHTEN CABLE SET SCREW AT CALIPER FINAL CABLE TIGHTENING AT HANDLEBAR LEVERS

VERTICALLY ADJUST "OUTRIGGER" ONTO THE POST SO THAT THERE IS 3"-5" OF CLEARANCE ABOVE THE TOP OF THE DOGS SHOULDERS.
 ADJUST SHOCK ABSORBER CLAMPS SO THEY FACE THE REAR AND ARE LEVEL W/ THE D-RINGS ON HARNESS (WITH THE SCOOTER VERTICAL)
 SHORTEN CARBINDER CHAIN SO THAT A LITTLE TENSION IS ON RUBBER BAND WHEN DOG IS HARNESSSED IN FINAL POSITION

GETTING YOUR DOG GOING: OVERCOMING THE FEAR
 -PUT THE HARNESS ON YOUR DOG
 -GET YOUR DOG USED TO BEING UNDER THE BAR
 -WALK YOUR DOG AND THE SCOOTER WHILE HOLDING HIM UNDER THE BAR (GET HELPER & AVOID SHARP TURNS)
 -PICK UP THE PACE/JOG-FOCUS HIS ATTENTION FORWARD
 -FINALLY HOOK THE DOG INTO THE D-RINGS
 -HOLD THE DOG IN CASE HE STARTS TO THRASH
 -THEN WALK - THEN JOG - THEN FINALLY PUT YOUR WEIGHT ON THE SCOOTER AND KICK TO HELP
 -ALL THIS SHOULD TAKE 20 MIN. OR SO ON AVERAGE
 -DON'T WORRY ABOUT SPEED/PULLING YET - IT WILL COME

BEFORE GOING OUT SCOOTERING - CHECK EACH CLAMP FOR TIGHTNESS. ALWAYS CARRY A TIRE PUMP (KEEP THE TIRES HARD) & FLAT REPAIR KIT. HARNESSSES ARE SIZED SMALL SO THAT THE PADDED CHEST STRAP RIDES AS HIGH AS POSSIBLE ABOVE THE SHOULDER SO THAT IT DOESN'T RESTRICT LEG EXTENSION-SHORTEN THE 4 VERTICAL HARNESS STRAPS IF IT DOES. STURDY FOOTWEAR AND BICYCLE HELMETS ARE RECOMMENDED. THE DOG CAN SIT AND EVEN LIE DOWN WHILE STILL HARNESSSED IN NEVER LEAVE YOUR DOG UNATTENDED WHILE HARNESSSED INTO THE SCOOTER

RECOMMENDED
 ALUM. OPTION
 NO FLAT TIRE
 CLEARANCE
 TUBE